



DENSITY LINE ADJUSTABLE REAR TOE LINK, B8/B8.5 AUDI A4/S4/RS4, A5/S5/RS5, Q5/SQ5

[Density Line Adjustable Rear Toe Link, B8/B8.5 Audi
A4/S4/RS4, A5/S5/RS5, Q5/SQ5](#)



These high-quality adjustable toe links replace the factory fixed-geometry arms to allow for precise adjustments when aligning B8/B8.5 Audi vehicles.

About This Guide

This Assembly Guide documents the process of the proper configuration prior to installation with the 034Motorsport parts that you have just purchased! Pictures and part numbers may vary, but the process remains the same.

Getting Started

- Confirm you have received all of the parts included with your purchase, if there are missing components, please contact customerservice@034motorsport.com

Collect the necessary tools required for installation by reading the complete Assembly Guide.

Supplied Parts:

- (2x) billet toe link tubes
- (2x) right-hand thread Density bushings with jam nuts (4ZZ-0001)
- (2x) left-hand thread Density bushings with jam nuts (4ZZ-0002)
- (8x) spacers
- (2x) packets of anti-seize

Tools Needed:

- (2x) capable hands



Step A

Open hardware packages



Step B

Apply half packet of anti-seize to Density bushing



Step C

Run the jam nut down the shaft to disperse the anti-seize along the entire threaded portion

**Step D**

The right-hand thread Density bushing will thread into the hexagonal end of the billet tube



Step E

The left-hand thread Density bushing will thread into the cylindrical end of the billet tube

**Step F**

Install (2x) spacers into each Density bushing. The car will need to be aligned to set the final length

